

ELECTRICAL SAFETY RECALL

Breville Fast Slow Cooker (BPR200) Lid Gasket

Domestic programmable stainless steel electric pressure cooker.



Identification

- Units sold between October 2010 and October 2015 through electrical retailers and department stores nationally.
- Production date code (PDC) **1034 – 1511** inclusive. The production date code can be found within the rating label. The rating label is located on the back of the unit.
- Only BPR200 units with a white silicone lid gasket are affected.

Hazard

Scalding - incorrect fitting of the supplied white lid gasket may result in release of hot liquids.

Action required

Customers can continue to safely use the appliance, by following these simple instructions:

1. Check that the lid gasket is installed correctly before each use. Instructions are provided in the appliance's instruction manual and can also be found at www.breville.com.au/recall
2. Do not lean across the release vent when depressing.
3. Do not force the appliance open. After depressurising, it should be possible to open the appliance using only one hand.
4. Do not move the appliance when under pressure.

Consumers should contact Breville on 1300 727 424 (8.30am – 5.00pm AEST, Monday to Friday), email recall@breville.com.au or visit www.breville.com.au/recall to register for a new lid gasket kit, which will be sent to them by Breville, free of charge.

See www.recalls.gov.au for Australian product recall information.